

			A	V	R		S	I	G	N	A	L			
	G	E	N	E	R	A	T	O	R		V	1	.	0	

Duration 1s.

R	E	A	D	I	N	G		P	R	E	V	I	O	U	S
	C	O	N	F	I	G	U	R	A	T	I	O	N		

After last signal generator configurations has been read it is displayed on LCD:
It last was square impulse used, then it shows:

O	U	T	_		-		_							O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Signal can be changed with button "Mode1" by pressing it sequentially:
Above mentioned square signal.

O	U	T		/		/								O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Sawtooth signal

O	U	T		\		\								O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Reverse saw tooth

O	U	T	/	\	/	\	/	\						O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Triangle

O	U	T	~	~	~	~								O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Sine wave

O	U	T	-	N	O	I	S	E						O	F	F
F	R	E	Q	:					1	0	0	0		H	Z	

Random signal